Studio X3 | X4 | X5 | X6

DMX CHART 8 BIT

CHANNEL	CHANNEL MODE
1	Dimmer

DMX CHANNEL	VALUE	PERCENT	FUNCTION
1	0 – 255	0 – 100	Dimming

DMX CHART 16 BIT

CHANNEL	CHANNEL MODE	
1	Dimmer	
2	Dimmer fine	

DMX CI	HANNEL	VALUE	PERCENT	FUNCTION
HI	LO	0 – 65535	0 – 100	Dimming
1	2		0 = 100	Dimming