


Antennas



*optional accessories:
ADP UHF (470 - 1075 MHz)
AD 1800 (1400 - 2400 MHz)



www.sennheiser.com/download

Smart Assist

Download on the  **App Store** GET IT ON  **Google Play**

Sennheiser electronic SE & Co. KG
Am Labor 1, 30900 Wedemark, Germany
www.sennheiser.com

Printed in Germany
Publ. 03/24, 583962/A05




Evolution Wireless Digital
EW-D EM
EW-D SK
EW-D SKM-S

Quick Guide
Kurzanleitung
Guide rapide
Guida rapida
Guía de inicio rápido
Guia rápido
Beknopte handleiding
Krótka instrukcja obsługi
Snabbguide

Kort vejledning
Pikaohje
Γρήγορος οδηγός
Kisa Kilavuz
Краткая инструкция
快速指南
クイックガイド
퀵 가이드


Audio Out



XLR-3 6.3 mm

OR OR

Power supply






EU US UK AU KOR CN

Smart Assist


The **Smart Assist** app simplifies your workflow

- Smart Assist app provides automated setup, operation and monitoring using any iOS or Android device
- Intelligent setup automatically creates reliable wireless connections, no wireless expertise required
- Mobile access to all system settings centralizes control and eliminates the need for complicated menu navigation on each device
- Easy frequency allocation and wireless channel naming help to keep systems organized

Download on the  **App Store** GET IT ON  **Google Play**




In the box



Rack mount angles
Power supply adapters
Power supply


Battery



1 2 3

2 AA batteries (included) *optional: BA 70 rechargeable battery


Battery




1 2 3 4

2 AA batteries (included) *optional: BA 70 rechargeable battery

EW-D EM




LINK LED DATA LED UP DOWN SYNC ON/OFF SET ESC




audio outputs antenna inputs power supply

On/Off

EM Off -> On

 **EM/SK/SKM-S**
short on


SKM-S On -> Off




 **EM/SK/SKM-S**
long off

SK


Identify/Battery check

On -> Identify/Check


 **SK/SKM-S**
short Identify/Check

LINK LED SK/SKM-S		≤ 100 %
		≤ 60 %
		≤ 20 %

Display of synced EM




EW-D SKM-S



ON/OFF LINK LED DATA LED SYNC MUTE

EW-D SK



DATA LED LINK LED SYNC MUTE ON/OFF

Display

Antenna switching diversity

Mute lock

Mute

Frequency

App connection

Key lock

Menu

Radio frequency level

Transmitter audio level

Gain

Audio output level

Channel

Transmitter battery

Instruction Manual

LEDs

LINK LED	
	- Link ok - audio active
	- Link ok - audio muted or no capsule on SKM-S
	- Link ok - audio clip
	- No link
	- Link ok - Low transmitter battery
	- No link - Device switched off

DATA LED	
	Bluetooth active to - sync with transmitter - connect with app
	Firmware update in progress

EM

SKM-S

SK

Instruction Manual

Sync

EM

SKM-S

SK

short press

OR

short press

short press

Instruction Manual

Menu

Gain

AF Out

Mute Lock

Auto Scan

Channel

Tune

Reset

Instruction Manual

www.sennheiser.com/download

Instruction manual
Bedienungsanleitung
Notice d'emploi
Istruzioni per l'uso
Instrucciones de manejo
Manual de instruções
Gebruiksaanwijzing
Instrukcja obsługi
Bruksanvisning
Betjenings vejledning
Käyttöohje
Οδηγίες λειτουργίας
Kullanım kılavuzu
Инструкция по эксплуатации
使用说明书
取扱説明書
사용 설명서

Smart Assist

Available on the App Store

ANDROID APP ON Google play

Mute

SK

SKM-S

Mute Lock

Instruction Manual

Key lock

press both

unlocked

locked

Instruction Manual

Color coding sets

optional accessories for EM, SK and SKM-S

wireless link 1:

wireless link 2:

etc.

etc.

Instruction Manual

SKM-S

Instruction Manual

ME 2

ME 3

ME 4

25 cm (10")

2...3 cm (1")

Instruction Manual