

000000MIPRO Wireless Frequency Chart

TV Channel	MHz					Antenna	band/color
15	476-482	480					
16	482-488		482				
17	488-494						
18	494-500						
19	500-506					2TB010	5E Brown
20	506-512	5E			5A		
21	512-518		5UA			2TB001	5UA Brown
22	518-524		518				
23	524-530						
24	530-536						
25	536-542						
26	542-548	544		542			
27	548-554	540	554	5NC		2TB002	5EA Blue
28	554-560		554				
29	560-566			566			
30	566-572			566			
31	572-578	5F		5ND		2TB003	5UB Blue
32	578-584					2TB011	5F Brown
33	584-590		5US	590		2TB003	5UB Blue
34	590-596		590				
35	596-602						
36	602-608	604	5NU to 608			2TB003	5UB Blue
37	608-614						
38	614-620						
39	620-626		626		620		
40	626-632		626		6A	2TA021	6A-B Blue
41	632-638	636					
42	638-644				644		
43	644-650				644		
44	650-656				6B	2TA021	6A-B Blue
45	656-662		6UA			2TB005	6UA Purple
46	662-668	6E	662		668	2TB012	6E Purple
47	668-674				668		
48	674-680				6C	2TA022	6C-7A Blue
49	680-686						
50	686-692				692		
51	692-698		698				
52	698-704	700					
						2TA027	9A-B Green