

DMX TRAITS

CHANNEL		DMX VALUE	FUNCTION
3CH	4CH		
1	1		Strobe
		0-31	LED off
		32-63	LED on
		64-95	Strobe Slow > Fast
		96-127	LED on
		128-159	Strobe Pulse Slow > Fast
		160-191	LED on
		192-223	Random Strobe Slow > Fast
		224-255	LED on
2	2	0-255	Dimmer
	3	0-255	Dimmer Fine
3	4		Dim Curves
		0-20	Standard
		21-40	Stage
		41-60	TV
		61-80	Architectural
		81-100	Theatre
		101-120	Stage 2
		121-255	Default to Unit Setting