




SL PASC 4

Quick Guide
 Kurzanleitung
 Guide de démarrage rapide
 Guida rapida
 Instrucciones resumidas
 Instruções resumidas
 Beknopte gebruiksaanwijzing
 Krótka instrukcja obsługi
 Snabbguide

Kort vejledning
 Pikaohje
 Γρήγορος οδηγός
 Kısa Kılavuz
 Краткая инструкция
 快速指南
 快速使用指南
 クイックガイド
 퀵 가이드



SENNHEISER



www.sennheiser.com/download


Sennheiser electronic GmbH & Co. KG

Am Labor 1, 30900 Wedemark, Germany
www.sennheiser.com

Publ. 12/23, 583929/A02

SL PASC 4

Operating elements



Specifications

Frequency range	1,880 - 1,930 MHz
Insertion loss	-8 dB typ.
Port to port isolation	26 dB min.
Input / Output return loss	-14 dB max
Connectors	AC coupled ports
Max. input power	1.5 W max
Dimensions	210 x 160 x 41 mm
Weight	663 g
Operating temperature	-40 to 85 °C
Relative humidity	max. 95 % (non-condensing)

Accessories


Remote antennas and maximum cable lengths




Instruction Manual
SpeechLine Digital Wireless

www.sennheiser.com/download

A: 4x SL Rack Receiver DW + AWM 2



B: 8x SL Rack Receiver DW + AWM 4



Instruction manual | Bedienungsanleitung | Notice d'emploi | Istruzioni per l'uso | Instrucciones de manejo | Manual de instruções | Gebruiksaanwijzing | Instrukcja obsługi | Bruksanvisning | Betjeningsvejledning | Käyttöohje | Οδηγίες λειτουργίας | Kullanım kılavuzu | Инструкция по эксплуатации | 使用说明书 | 使用説明書 | 取扱説明書 | 사용 설명서