



## Dual 4/8-Way DMX Splitter + Booster



Switch Status LED (Off = 4-Way, On = 8-Way)

Insert a small, thin object (like a paperclip) to press the mode switch to toggle between dual 4/8-way modes. Terminator switch ends DMX In A & B (front/rear). Use if no devices are downstream.



Rear A/B inputs with DMX Thru allow alternate input access and signal pass-through for daisy-chaining.