TABLE 1. 8-BIT MODE (DEFAULT)

DMX CHANNEL	PARAMETER	DEFAULTS	RANGE DMX	DESCRIPTION
1	Intensity (16-bit high)	0	0 - 255	16-bit intensity (dimmer) control
2	Strobe	0	0 1 - 255	Open Strobe speed Slow>>>>>>>>>>>>>>>>>>>>Fast (Rate TBC) XX Hz>>>>>>>>>>>>>>>>>>XX Hz

TABLE 2. 16-BIT MODE

DMX CHANNEL	PARAMETER	DEFAULTS	RANGE DMX	DESCRIPTION
1	Intensity (16-bit high)	0	0 - 255	16-bit intensity (dimmer) control
2	Intensity (16-bit low)	0	0 - 65535	Open
3	Strobe	0	0 1 - 255	Open Strobe speed Slow>>>>>>>>>>>>>>>>>>>>Fast (Rate TBC) XX Hz>>>>>>>>>>>>>>>>>>XX Hz