



**OWNER'S MANUAL
THUNDER SERIES
HOME THEATER CUSTOM SPEAKERS**


Thank you for choosing MTX THUNDER Series speakers for your home theater or distributed audio system. Properly installed and operated, these speakers will provide years of worry-free listening pleasure.

KEY FEATURES

- Kevlar Woofer Delivers Accurate Low Frequencies
- Teteron Tweeter Produces Clear High Frequencies While Minimizing Resonance
- Pivoting Tweeter Allows for Proper Sound Imaging
- 12dB/octave High Pass and 6dB/octave Low Pass Crossover
- Mylar High Pass Capacitors
- High Temperature Woofer and Tweeter Voice Coil Wire
- Compression Style Input Terminal Accepts Up to 8-AWG Speaker Wire
- Front Mounted Tweeter Level Control
- Round and Square Paintable Magnetic Grilles Included (Square Only w/ T265LCR)

SPEAKER INSTALLATION

MTX THUNDER Series speakers can be installed in both in-ceiling and in-wall applications allowing them to blend within any interior decorating scheme. Speaker placement is critical to maximizing the performance of the speakers within the system. Achieve the best stereo reproduction by installing two loudspeakers an equal distance from the listener's position and separated so that the speakers and the listener form an equilateral triangle, with all sides of the triangle being the same length. In multi-channel applications the same principle applies for both the front and rear speakers with the addition of a center channel speaker directly in front of the listener's position.



CUTTING THE SPEAKER HOLE

Before cutting any speaker holes, it is important to check for electrical wiring, plumbing, conduit, studs, or other obstacles that may exist in the intended installation spot. Remember that the grille and flange are larger than the speaker cut-out. Ensure there is room on all sides of the desired location to accommodate the entire speaker.

1. Use the included cut-out template to mark the cut-out pattern on the wall or ceiling once it has been determined to be a safe location with no obstructions.
2. Use a sabre saw, keyhole saw, or sharp utility knife to cut the hole following the traced pattern. Use caution when cutting the hole to prevent unnecessary damage to the surrounding surface.
3. Clear the hole of any debris or other material that will prevent speaker installation.

INSTALLING THE SPEAKER

1. Connect the speaker wires previously run to the install location ensuring that the ends are stripped and the inner copper wire is exposed. Press down on the compression terminals and insert the speaker wire into each terminal ensuring that polarity is maintained with the positive wire connected to the + terminal and the negative wire connected to the - terminal.
2. The speaker includes four front panel Phillips screws that operate the dog legs that will attach the speaker to the ceiling or wall material.
3. Using a screwdriver or power drill on low setting turn each screw clockwise until the dog leg firmly secures itself to the ceiling or wall material. Use caution to not overtighten the dog legs causing them to crack or break.
4. Angle the tweeter toward the listening position if necessary to ensure proper imaging by pressing on the outer edge of the tweeter opposite from the desired angle direction.
5. Attach either the round or square magnetic grille, make the speaker wire connections at the source, and turn on a signal to test the speaker(s).

TWEETER LEVEL ADJUSTMENT

The output of the tweeter can be adjusted to compensate for speaker placement / listening positions that are less than ideal. The 0dB setting is designed for maximum output of the entire system. This can be used if a brighter sound is desired. The -3dB setting is designed to lower the tweeter output from the 0db setting. This will soften the sound of the inwall speaker and give the smoothest frequency response on axis.

PAINTING THE GRILLES

MTX THUNDER Series speakers include magnetic metal grilles that can be painted to match ceiling or wall colors allowing them to blend into the room. Spray application will provide excellent results. The cloth inserts in the grilles should be removed before the grilles are painted and they should be placed back in the grilles once the paint is dry.

SPECIFICATIONS

T625CW

Speaker Type: 2-Way In-Wall / In-Ceiling
Tweeter: Pivoting 1" Teteron
Woofer: 6.5" Kevlar with Rubber Surround
Impedance: 6Ω
Sensitivity: 88dB (2.83V/1M)
Frequency Adjustments: 0 and -3dB
Frequency Response: 35Hz - 30kHz (-10dB)
RMS Power: 100-Watts
Dimensions: 8.74" x 8.74" x 3.66"
(222mm x 222mm x 93mm)
Mounting Depth: 3.44" (87.5mm)
Cut Out: 7.87" (200mm)

T625ACW

Speaker Type: 2-Way Angled In-Wall / In-Ceiling
Tweeter: Pivoting 1" Teteron
Woofer: 6.5" Kevlar with Rubber Surround
Impedance: 6Ω
Sensitivity: 88dB (2.83V/1M)
Frequency Adjustments: 0 and -3dB
Frequency Response: 35Hz - 30kHz (-10dB)
RMS Power: 100-Watts
Dimensions: 10.26" x 10.26" x 5"
(260.5mm x 260.5mm x 127mm)
Mounting Depth: 4.80" (122mm)
Cut Out: 9.41" (239mm)

T825CW

Speaker Type: 2-Way In-Wall / In-Ceiling
Tweeter: Pivoting 1" Teteron
Woofer: 8" Kevlar with Rubber Surround
Impedance: 6Ω
Sensitivity: 89dB (2.83V/1M)
Frequency Adjustments: 0 and -3dB
Frequency Response: 31Hz - 30kHz (-10dB)
RMS Power: 125-Watts
Dimensions: 10.26" x 10.26" x 3.90"
(260.5mm x 260.5mm x 99mm)
Mounting Depth: 3.70" (94mm)
Cut Out: 9.41" (239mm)

T265LCR

Speaker Type: Dual 6.5" LCR
Tweeter: 1" Teteron
Woofer: 6.5" Kevlar with Rubber Surround
Impedance: 6Ω
Sensitivity: 88dB (2.83V/1M)
Frequency Adjustments: 0 and -3dB
Frequency Response: 27Hz - 30kHz (-10dB)
RMS Power: 150-Watts
Dimensions: 15.20" x 9.45" x 3.43"
(386mm x 240mm x 87mm)
Mounting Depth: 3.23" (82mm)
Cut Out: 14.25" x 8.54" (362mm x 217mm)

© 2015 Mitek Corporation. All rights reserved. MTX is a trademark of Mitek Corporation. Designed and Engineered in the U.S.A.

Due to continual product development, all specifications are subject to change without notice.

MTX Audio, 4545 East Baseline Rd. Phoenix, AZ 85042 U.S.A. 1-800-225-5689

MTX005291 RevA 10/15 • 21A10475 • AW0015221